

# PUMP SPARES-Bowl & Impeller



**SP 2/3**



**SP 5**



**SP 9**



**SP 9 / 12 / 17**



**SP 30**



**SP 46 / 60**



**SP 46 / 60**



# PUMP SPARES



**COUPLING**



**SPLIT CONE & NUT**



**NECKRING**



**IMPELLER WEAR RING**



**DIFFUSER RUBBER**



**TOP BEARING BUSH**



**STRAINER**



**VALVE SEAT**



**STRAP & CABLE GUARD**



**CFT SPACING WASHER**



**SS 304 STUD & NUT**

# PUMP SPARES-PUMP INLET-PUMP SUCTION



**SP 2 / 3 / 5**



**6" TO 6"**



**6" TO 4"**



**8" TO 6"**



**8" TO 8"**



# SUBMERSIBLE PUMP SHAFT



20 mm SHAFT



22 mm SHAFT



25 mm SHAFT



## PUMP NRV / OUTLET



4"



2" / 2.5" (6")



3" (6")



4" (6")



5" (8")



6" (10")



Fabricated 2" & 2.5"



Fabricated 3"



Fabricated 4"

